

# Algoflon® DF 261 F polytetrafluoroethylene

Algoflon® DF 261 F is a white fine coagulated powder. It is designed for paste extrusion in low reduction ratio (RR) range. It is recommended for manufacture high tenacity items as full density tapes, fibers and membranes.

Algoflon® DF 261 F shows large processing range and higher productivity.

Main features of Algoflon® DF 261 F include:

- Low sintering temperature
- · Excellent tenacity
- · Good stretchability
- · Good dimension stability
- Higher productivity

$\overline{}$	n	$\overline{}$	×	$\sim$

Material Status	<ul> <li>Commercial: Acti</li> </ul>	ve		
Availability	<ul><li>Asia Pacific</li><li>Europe</li></ul>		• North Americ	a
Features	<ul><li>Chemical Resista</li><li>Good Processing</li><li>Good Stretchabili</li></ul>	Stability	<ul><li>Good Thermo</li><li>Low Friction</li></ul>	al Stability
Uses	<ul><li>Aerospace Applic</li><li>Automotive Applic</li><li>Electrical/Electror</li><li>Fibers</li></ul>	cations	<ul><li>Industrial Applications</li><li>Membranes</li><li>Wire &amp; Cable Applications</li><li>Yarn</li></ul>	
Agency Ratings	• FDA¹			
Appearance	• White			
Forms	• Powder			
Physical		Typical V	alue Unit	Test method
Specific Gravity			2.15	ASTM D792
Apparent (Bulk) Density			0.35 g/cm³	ASTM D4895
Average Particle Size			600 µm	Internal Method
Bulk Density			475 g/I	GE
Stretchability		1	500 %	Internal Method
Mechanical		Typical V	alue Unit	Test method
Tensile Strength			35.0 MPa	ASTM D4895
Elongation at Break			350 %	ASTM D4895
Thermal		Typical V	alue Unit	Test method
Thermal Instability Index		<	15.0	ASTM D4895
Additional Information		Typical V	alue Unit	Test method
Reduction Ratio - range		10.0 to		Internal Method
Rheometer Pressure - @ RR 400:1			50.0 MPa	ASTM D4895

### Algoflon° DF 261 F polytetrafluoroethylene

#### Processing

- Algoflon® DF 261 F is processed according to methods conventionally used for paste extrusion. Initially
  the powder is mixed with a lubricant to produce a paste. This is then compacted into a preform and
  extruded through a finishing die using a ram extruder. Further processing as calendering, removal of
  lubricant, stretching and sintering are carried out to make final products such as yarns.
- Mixing, performing, calendaring, stretching and sintering steps must all be carefully coordinated and controlled to avoid production waste.

#### Storage and Handling

- Algoflon® PTFE fine coagulated powders must be stored and handled carefully to avoid excessive shearing and particle fibrillation. Fibrillation is irreversible and damaged particles can appear as defects in manufactured articles.
- PTFE fine coagulated powders must be handled below 19°C because above this temperature, the powders are softer and can be more easily laminated. It is recommended sieving of powders below 19°C before adding lubricant. Strong vibrations and shocks must be avoided as much as possible for prevent lumps formation.
- Storage and transportation should be carried out in the range 5 19°C. Moreover, the powders must be stored in a dry room because the absorption of moisture could negatively affect its processing.
- Storage and handling facilities should be clean since even very small foreign particles can cause defects in finished products. Keep resin drums closed and clean. Good housekeeping and careful handling are essential.

#### Safety and Toxicology

- Before using Algoflon® PTFE fine coagulated powders consult the product Material Safety Data Sheet and follow all label directions and handling precautions.
- As with all PTFE materials, handling and processing should only be carried out in well ventilated areas.
   Vapor extractor units should be installed above processing equipment. Fumes must not be inhaled and eye and skin contact ought to be avoided. In case of skin contacts wash with soap and water. In case of eye contact flush with water immediately and seek medical help. Do not smoke in areas contaminated with powder, vapor or fumes.
- · See Material Safety Data Sheet for detailed advice on waste disposal methods.

#### Packaging

• Algoflon® DF 261 F is packaged in 25 kg non returnable drums.

#### Additional Technical Information

 For Material Safety Data Sheet or additional technical information consult your Syensqo sales representative, or contact us by e-mail.

#### Notes

Typical properties: these are not to be construed as specifications.

<sup>1</sup> Please contact your account manager to request a food contact statement.

## Algoflon° DF 261 F polytetrafluoroethylene

### www.syensqo.com

Safety Data Sheets (SDS) are available by emailing us or contacting your sales representative. Always consult the appropriate SDS before using any of our products.

Neither Syensqo nor any of its affiliates makes any warranty, express or implied, including merchantability or fitness for use, or accepts any liability in connection with this product, related information or its use. Some applications of which Syensqo's products may be proposed to be used are regulated or restricted by applicable laws and regulations or by national or international standards and in some cases by Syensqo's recommendation, including applications of food/feed, water treatment, medical, pharmaceuticals, and personal care. Only products designated as part of the Solviva® family of biomaterials may be considered as candidates for use in implantable medical devices. The user alone must finally determine suitability of any information or products for any contemplated use in compliance with applicable law, the manner of use and whether any patents are infringed. The information and the products are for use by technically skilled persons at their own discretion and risk and does not relate to the use of this product in combination with any other substance or any other process. This is not a license under any patent or other proprietary right.

All trademarks and registered trademarks are property of the companies that comprise the Syensqo or their respective owners.

© 2024 2023 Syensqo. All rights reserved.

